



# Exhaust air module NIBE FLM S45





# Table of Contents

1	<i>Important information</i> _____	4	7	<i>Program settings</i> _____	25
	Safety information _____	4		Start guide _____	25
				Menu system _____	25
2	<i>Delivery and handling</i> _____	7	8	<i>Service</i> _____	27
	Transport _____	7		Service actions _____	27
	Assembly _____	7	9	<i>Disturbances in comfort</i> _____	28
	Supplied components _____	8		Troubleshooting _____	28
	Compatible NIBE heat pumps _____	8	10	<i>Accessories</i> _____	29
	Removing the covers _____	8		11	<i>Technical data</i> _____
	Mounting _____	8		Dimensions and setting-out coordinates _____	30
3	<i>The design of the exhaust air module</i> _____	10		Technical specifications _____	31
	Pipe connections _____	11		Electrical circuit diagram _____	32
	HVAC components _____	11		<i>Item register</i> _____	34
	Sensors etc. _____	11		<i>Contact information</i> _____	39
	Electrical components _____	11			
	Ventilation _____	11			
	Miscellaneous _____	11			
4	<i>Pipe and ventilation connections</i> _____	12			
	General pipe connections _____	12			
	Dimensions and pipe connections _____	13			
	Brine side _____	13			
	Condensation water hose _____	14			
	Installation alternative _____	14			
	General ventilation connection _____	16			
	Ventilation flow _____	16			
	Adjusting ventilation _____	16			
	Dimension and ventilation connections _____	16			
5	<i>Electrical connections</i> _____	17			
	General _____	17			
	Connections _____	17			
6	<i>Commissioning and adjusting</i> _____	21			
	Preparations _____	21			
	Filling and venting _____	21			
	Start-up and inspection _____	22			

# 1 Important information

## Safety information

This manual describes installation and service procedures for implementation by specialists.

The manual must be left with the customer.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This is an original manual. It may not be translated without the approval of NIBE.

Rights to make any design or technical modifications are reserved.

©NIBE 2021.

If the supply cable is damaged, only NIBE, its service representative or similar authorised person may replace it to prevent any danger and damage.

### SYMBOLS



#### NOTE

This symbol indicates danger to person or machine.



#### Caution

This symbol indicates important information about what you should consider when installing or servicing the installation.

### MARKING

**CE** The CE mark is obligatory for most products sold in the EU, regardless of where they are made.

**IP21** Classification of enclosure of electro-technical equipment.




Danger to person or machine.



Read the User Manual.

### SERIAL NUMBER

The serial number can be found at the bottom left inside the front cover.



#### Caution

You need the product's (14 digit) serial number for servicing and support.

### RECOVERY



Leave the disposal of the packaging to the installer who installed the product or to special waste stations.

When disposing of the product, its constituent materials and components, e.g. compressors, fans, circulation pumps and circuit boards, must be disposed of at a special waste station or dealer who provides this type of service.

To access the separate components, refer to the section that shows the construction of the product. No special tools are required for access.

Improper disposal of the product by the user results in administrative penalties in accordance with current legislation.

## INSPECTION OF THE INSTALLATION

In addition, fill in the page for the installation data in the User Manual.

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. Current regulations require the exhaust air module to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. In addition, fill in the page for the installation data in the User Manual.

✓	<i>Description</i>	<i>Notes</i>	<i>Signature</i>	<i>Date</i>
Ventilation				
	Setting the ventilation flow			
Brine				
	Non-return valve			
	System flushed			
	System vented			
	Antifreeze			
	Expansion vessel			
	Particle filter			
	Safety valve			
	Shut off valves			
	Circulation pump setting			
	Checking the condensation water seal			
	Trim valve			
Electricity				
	Connections			
	Phase voltage			
	Supply connected 230 V			
	Circuit fuses			

# 2 Delivery and handling

## Transport

The exhaust air module should be transported and stored in the dry.


## Assembly

FLM S45 is installed on top of the ground source heat pump or independently on brackets. Noise from the circulation pump or fan can be transferred to the brackets.

- Install with its back to an outside wall, ideally in a room where noise does not matter, in order to eliminate noise problems. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem.
- Wherever the unit is located, walls to sound sensitive rooms should be fitted with sound insulation.
- Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.

### INSTALLATION AREA

Leave a free space of 800 mm in front of the product. Leave free space between FLM S45 and wall/fittings/cables/pipes etc. It is recommended that a space of at least 10 mm is left to reduce the risk of noise and of any vibrations being propagated.



#### NOTE

Ensure that there is sufficient space (300 mm) above FLM S45 for connecting ventilation ducts.

# Supplied components




Trim valve (RN1)  
Ø 15 mm



Non-return valve (RM1)  
Ø 32 mm



Condensation water hose  
Ø 20 mm



2 x screws (T25) for in-  
stalling FLM S45 on NIBE  
heat pump

## LOCATION

The bag of supplied items is placed on top of FLM S45.

# Compatible NIBE heat pumps

FLM S45 ventilates the building and preheats the brine, regardless of which ground source heat pump is installed, but when FLM S45 is installed together with a compatible ground source heat pump, it is possible to adjust settings and read off sensor values etc. in the heat pump's display.


## COMPATIBLE PRODUCTS

- S1155
- S1255

# Removing the covers


## FRONT COVER

1. Remove the service cover by pulling it straight out.



## SIDE COVERS

1. Undo the screws at the upper edge.
2. Lift the side hatches upwards and twist the cover outwards slightly.
3. Assembly takes place in the reverse order.



# Mounting

## CONNECTING TO COMPATIBLE PRODUCT

1. Remove the front cover from the heat pump.
2. Remove the top panel from the heat pump (installed with 6 screws).
3. Remove the cover in front of the circuit board.







### Caution

A description of the removal of panels and covers can be found in the manual for the compatible product.

4. Remove the display.




5. Install FLM S45 from the top and slide into position.




6. Secure FLM S45 with the 2 screws supplied.

7. Route the communication cable from FLM S45 as illustrated.







### INSTALLING ON BRACKETS

FLM S45 can also be installed freestanding on the bracket BAU 40.



# 3 The design of the exhaust air module



## Pipe connections

XL6	Connection, brine in, compression ring Ø 15 mm
XL7	Connection, brine out, compression ring Ø 15 mm
XL31	Ventilation connection exhaust air, Ø 160 mm
XL32	Ventilation connection extract air, Ø 160 mm
XL40	Drip-pan drain

## HVAC components

EP16	Heat exchanger
GP2	Circulation pump, brine
QM21	Venting brine

## Sensors etc.

BT20	Temperature sensor, exhaust air
BT21	Temperature sensor, extract air
BT26	Temperature sensor, collector in
BT27	Temperature sensor, collector out

## Electrical components

AA5	Accessory card
AA100	Joint card
SF1	Switch, position 0 - 1, main switch
SF2	Switch, position 0 - 1, circulation pump
SF3	Potentiometer
W1	Cord with connection plug
W6	Communication cable

## Ventilation

GQ2	Exhaust air fan
HQ10	Exhaust air filter

## Miscellaneous

PZ1	Type plate
-----	------------

Designations according to standard EN 81346-2.

# 4 Pipe and ventilation connections














## General pipe connections

Pipe installation must be carried out in accordance with current norms and directives.


Lowest permitted temperature of incoming brine is -8°C.

Pipes and other cold surfaces must be insulated with diffusion-proof material to prevent condensation.

### SYMBOL KEY

Symbol	Meaning
	Shut-off valve
	Non-return valve
	Circulation pump
	Expansion vessel
	Filterball
	Fan
	Pressure gauge
	Safety valve
	Trim valve
	Manual reversing valve/shunt
	Bore hole
	Ground collector
	Heat pump

### OUTLINE DIAGRAM






The brine system must be fitted with a pressure expansion vessel and a particle filter or filterball. In order to make any future servicing easier, one or more shut-off valves should be fitted.



### NOTE

Venting may be necessary during installation and after a period of use. Venting takes place through vent valve (QM21). When venting, set the switch for the circulation pump (SF2) to position "0".


# Dimensions and pipe connections



# Brine side

## OUTPUT TRANSFER TO BRINE

*Output transfer to brine*




The diagram shows the power that is transferred from the ventilation air to the brine at 0°C and 5°C, and applies to an air temperature of +20°C and 50% relative air humidity.

## EXPANSION VESSEL

The brine circuit must be provided with pressure expansion vessel (CM3). If there is a level vessel (CM2), this should be replaced. The brine side must be pressurised to at least 0.5 bar.

To prevent malfunctions, the pressure expansion vessel should be dimensioned as set out in the diagram. The pressure expansion vessel covers the temperature range from -10°C to +20 °C for the brine at a pre-pressure of 0.5 bar and with the safety valve's opening pressure set at 3 bar.


*Expansion vessel*



# Condensation water hose

1. Connect the condensation water hose to the drip-pan drain (XL40).
2. Shape the hose into a water seal (see image). If FLM S45 is connected to S1255, there is space for the hose and the water seal in the heat pump's insulation.
3. Route the hose to a floor drain or similar.
4. Refill the water seal with water.


Ensure that the end of the hose runs out above the water level in the floor drain. The hose must be easily accessible for future cleaning.



# Installation alternative


## ANOTHER HEAT PUMP

When FLM S45 is installed together with another heat pump, the brine circuit is supplied with a trim valve (RN1). This is necessary for adjusting the brine flow.




## FLM COOLING

Where cooling is prioritised, FLM S45 can be installed in the brine circuit after the heat pump in the direction of flow.




FLM cooling Requires an external fan (GQ4), four dampers that are controlled by two motors (QM40), (QM41) and a non-return damper (RM2). A room sensor (AZ10-BT50) is also required in one of the rooms where cooling is required. For electrical connection, see page 19.

The external fan (GQ4) takes over ventilation, which is led out of the house without recovery. At the same time, FLM S45 circulates air to and from other rooms where cooling is required, normally two to three bedrooms.



Normal operation.



**NOTE**

When installing with cooling, the supply air ducts have to be insulated with diffusion-proof material (at least PE30 or equivalent) along their entire length.

# General ventilation connection

- Ventilation installation must be carried out in accordance with current norms and directives.
- Connections must be made via flexible hoses, which should be installed so that they are easy to replace.
- Provision must be made for inspection and cleaning of the duct.
- Make sure that there are no reductions of cross-sectional area in the form of creases, tight bends, etc., since this will reduce the ventilation capacity.
- The air duct system must be a minimum of air tightness class B.
- To prevent fan noise being transferred to the ventilation devices, install silencers in suitable locations in the duct system.
- The extract air duct and ducts intended for supply air for FLM cooling have to be insulated with diffusion-proof material (at least PE30 or equivalent) along their entire length.
- Ensure that the condensation insulation is fully sealed at any joints and/or at lead-in nipples, silencers, roof cowls or similar.
- A duct in a masonry chimney stack must not be used for extract air.

## EXHAUST AIR DUCT /KITCHEN FAN

Exhaust air duct (kitchen fan) must not be connected to FLM S45.

To prevent food vapour being transferred to FLM S45 the distance between the kitchen fan and the exhaust air device must be considered. The distance should not be less than 1.5 m, but this can vary between different installations.

Always use a kitchen fan when cooking.

# Ventilation flow

Connect FLM S45 so that all the exhaust air, except kitchen duct air (kitchen fan), passes through the heat exchanger (EP16) in the product.

The ventilation flow must comply with the applicable national standards.

If the exhaust air module is connected to a compatible heat pump, set the ventilation capacity in the heat pump's menu system (menu 7.1.4.1). Otherwise, set the ventilation capacity via potentiometer (AA5-SF3).


# Adjusting ventilation

To obtain the necessary air exchange in every room of the house, the exhaust air devices must be correctly positioned and adjusted and the fan in the exhaust air module adjusted.

Immediately after installation adjust the ventilation so that it is set according to the projected value of the house.

Incorrect adjustment of the ventilation may lead to reduced installation efficiency and thus poorer operating economy, a poorer indoor climate and moisture damage in the building.

# Dimension and ventilation connections





# 5 Electrical connections

## General



### NOTE

All electrical connections must be carried out by an authorised electrician.

Electrical installation and wiring must be carried out in accordance with national provisions.

FLM S45 must not be powered during installation.

- To prevent interference, sensor cables to external connections must not be laid close to high voltage cables.
- The minimum area of communication and sensor cables to external connections must be 0.5 mm<sup>2</sup> up to 50 m, for example EKKX, LiYY or equivalent.
- Disconnect FLM S45 before insulation testing the house wiring.

For the exhaust air module wiring diagram, see page 32.

## Connections


### CONNECTING TO COMPATIBLE HEAT PUMP

#### Connection of supply to FLM S45


FLM S45 is connected to a earthed single-phase wall socket or a permanent installation. For permanent installations, FLM S45 must be preceded by a circuit breaker with at least a 3 mm breaking gap.

#### Connecting the communication to FLM S45 no. 1

S1155/S1255: The communication cable (W6) with connector connects to contact X6 on the PCB (AA2) in the main product.



The DIP switch (AA5-S2) has to be set as follows.




### Connecting the communication to FLM S45 no. 2-4

FLM S45 no. 2 connects directly to the main product on the PCB (terminal block AA2-X30).



FLM S45 no. 3 connects to the accessory board's terminal block (AA5-X4) in FLM S45 no. 2.

FLM S45 no. 4 connects in a similar way in FLM S45 no. 3.




FLM S45 2-4 can be connected in a similar way to a previously installed accessory and its accessory board.

The DIP switch (AA5-S2) must be set as follows.




AA5-S2

FLM S45 no. 2



AA5-S2


FLM S45 no. 3



AA5-S2

FLM S45 no. 4

## CONNECTING TO ANOTHER HEAT PUMP



### Connecting the supply

FLM S45 is connected to a earthed single-phase wall socket or a permanent installation. For permanent installations, FLM S45 must be preceded by a circuit breaker with at least a 3 mm breaking gap.


### Circulation pump for brine (GP2)

Disconnect the PWM cable from terminal block AA5-X2:7-8. Insulate the wires properly.

### Connecting communication

For installation with another heat pump, do not connect the communication cable (W6).

The DIP switch (AA5-S2) must be set as follows.



AA5-S2

## OPTIONAL CONNECTIONS

### Room sensor for FLM cooling

For optimum function, a separate room sensor (AZ10-BT50) should be connected when installing with cooling. This sensor is placed in the room that is to be kept coolest. The room sensor has up to three functions:

- Offers the opportunity to set a different target temperature in the room that is to be kept coolest.
- Show current room temperature in the display on the heat pump.
- Provides the opportunity to activate FLM cooling.

Install the sensor in a neutral position where the set temperature is wanted.

A suitable location is on a free inner wall in a hall approx. 1.5 m above the floor. It is important that the sensor is not prevented from measuring the correct room temperature, for example by being located in a recess, between shelves, behind a curtain, above or close to a heat source, in a draught from an external door or in direct sunlight. Closed radiator thermostats can also cause problems.



### Connection of room sensor for FLM cooling

Room sensor (AZ10-BT50) is connected to any AUX input (AA2-X28:3-11) and to GND (AA2-X29) in the compatible main product.

### Connection of duct fan and damper for FLM cooling

Connect the fan (GQ4) and the damper (QM40) (QM41) for AA5-X9:4 (signal), AA5-X9:3 (N) and AA5-X10:2 (230V).

The connection on AA5-X10 and PE are occupied and these must be spliced with a clamp.



# 6 Commissioning and adjusting

## Preparations

1. Make sure the heat pump is switched off.
2. Check that the filling valves are fully closed.

## Filling and venting




### Caution

Insufficient venting can damage internal components in FLM S45.

### FILLING AND VENTING THE BRINE SYSTEM

When filling the brine system, mix the water with anti-freeze in an open container. The mixture should be protected against freezing down to about -15°C. The brine is topped up by connecting a filling pump.

1. Check that the level vessel is replaced with an expansion vessel.
2. Check the brine system for leakage.
3. Connect the filling pump and return line on the brine system's filling connection (accessory).
4. Close the reversing valve in the filling connection.
5. Open the valves on the filler connector.
6. Start the filling pump.
7. Fill until liquid enters the return pipe.
8. Vent the brine system with vent valve (QM21) on FLM S45.
9. Close the valves on the filler connector.
10. Open the reversing valve in the filling connection.



### NOTE


Venting may be necessary during installation and after a period of use. Venting takes place through vent valve (QM21). When venting, set the switch for the circulation pump (SF2) to position "0".

# Start-up and inspection



## NOTE

There must be brine in the system, before the switch for the circulation pump (SF2) is set to "1".



## STARTING-UP WITH ANOTHER HEAT PUMP

1. Set the main switch (SF1) and the switch for the circulation pump (SF2) on FLM S45 to position "1".
2. Check that the fan (GQ2) and the circulation pump (GP2) are in operation.
3. Set the speed of the fan using the potentiometer (SF3).
4. Start the heat pump.

## START-UP WITH COMPATIBLE HEAT PUMP

1. Set the main switch (SF1) and the switch for the circulation pump (SF2) on FLM S45 to position "1".
2. Start the heat pump.
3. Follow the instructions in the display's start guide. If the start guide does not start when you start the heat pump, you can start it manually in menu 7.7.
4. Check that the fan (GQ2) and circulation pump (GP2) are running.

## STARTING-UP WITH VENTILATION ONLY

It is possible to run FLM S45 with only ventilation, e.g. before the brine side is ready for connection. In this mode, the circulation pump must be switched off.

1. Follow the instructions on page 22, but leave the switch for circulation pump (SF2) in "0" mode.
2. When the brine side is connected, the switch for circulation pump (SF2) is set to "1" mode.

## SETTING THE VENTILATION

The ventilation must be set according to applicable standards. The fan speed is set in menu 7.1.4.1.

The ventilation must be set according to applicable standards. If FLM S45 is connected to a compatible heat pump, the setting is adjusted in menu 7.1.4.1. Otherwise the ventilation is set via potentiometer (AA5-SF3).


Even if ventilation is roughly set at installation it is important that a ventilation adjustment is ordered and permitted.




### NOTE

Order a ventilation adjustment to complete the setting.

Ventilation capacity



Power direct current fan



## SETTING THE BRINE FLOW

Set the brine flow so that the temperature difference between the brine entering and leaving FLM S45 is 2–4°C. The temperature is measured using external measuring equipment.

Compatible heat pump: The brine flow over FLM S45 is regulated by the trim valve (RN1) and the circulation pump (GP2).

Other heat pumps: The brine flow over FLM S45 is regulated by the trim valve (RN1) and the brine pump in the heat pump.

Adjustments are made when the heat pump is in operation. Temperature difference applies at 20 °C room temperature and 0 °C in the brine.

The brine flow through FLM S45 will be from 0.1 l/s (360 l/h) to 0.15 l/s (540 l/h) at the above temperature difference, depending on the ventilation flow.


When the heat pump is at a standstill, the internal circulation pump in FLM S45 gives from 0.085 l/s (306 l/h) to 0.125 l/s (450 l/h) in the return charging flow to the collector.

This applies to a heat pump with approximately 4 kW rated output.


For a 15 kW heat pump, the corresponding flow is from 0.09 l/s (324 l/h) to 0.14 l/s (504 l/h).

## SETTING PUMP SPEED


Set the speed of the circulation pump (GP2) in menu 7.2.2. For other heat pumps, the trim valve (RN1) is used to set the flow.



Capacity circulation pump



Output circulation pump





# 7 Program settings

The activation of FLM S45 can be performed via the start guide or directly in the menu system in the compatible heat pump.

The main product's software must be the latest version.



## Caution

Also see the Installer Manual for the main product.

## Start guide

The start guide appears upon first start-up after heat pump installation, but is also found in menu 7.7.

## Menu system

If you do not make all settings via the start guide or need to change any of the settings, this can be done in the menu system.

### MENU 7.2.1. - ADD/REMOVE ACCESSORIES

Activating/deactivating of accessories.

Select "exhaust air module 1-4".

### MENU 7.2.2 - EXHAUST AIR MODULE (FLM) (NIBE FLM/FLM S45)

#### *Continuous pump operation*

Setting range: on/off

#### *Pump speed*

Setting range: 1-100%

#### *Time between defrosts*

Setting range: 1 – 30 h

#### *Activate cooling*

Setting range: on/off

*continuous pump operation:* Select continuous operation of the circulation pump in the exhaust air module.

*pump speed:* Here, you can set the speed of the exhaust air module's circulation pump.

*time between defrosts:* Here, you can set the minimum time that will pass between defrosts of the heat exchanger in the exhaust air module.

When the exhaust air module is in operation the heat exchanger is cooled so that ice builds up on it. When too much ice builds up the heat transfer capacity of the heat exchanger is reduced and defrosting is required. Defrosting warms up the heat exchanger so that the ice melts and runs off via the condensation hose.

Clean the exhaust air module's air filter regularly, how often depends on the amount of dust in the ventilation air.

*Activate cooling:* Here, you can activate cooling via the exhaust air module. When the function has been activated, the cooling settings are displayed in the menu system.

### MENU 7.1.4.1 - FAN SPEED, EXHAUST AIR

#### *Normal and Fan speed 1 – Fan speed 4*

Setting range: 0 – 100 %

Set the speed for the five different selectable speeds for the fan here.

### MENU 1.2.1 - FAN SPEED

Alternatives: normal and speed 1 – speed 4

The ventilation in the accommodation can be temporarily increased or reduced here.

When you have selected a new speed a clock starts a count down. When the time has counted down the ventilation speed returns to the normal setting.

If necessary, the different return times can be changed in menu 1.2.5.

The fan speed is shown in brackets (in percent) after each speed alternative.

### MENU 1.2.5 - FAN RETURN TIME

#### *speed 1 – speed 4*

Setting range: 1 – 24 h

Here, you select the return time for the temporary speed change (speed 1 – speed 4) of the ventilation in menu 1.2.1.

Return time is the time taken before the ventilation speed returns to normal speed.

### MENU 1.2.6 - FILTER CLEANING INTERVAL

#### *Months between filter cleaning*

Setting range: 1 – 24 months

Clean the FLM S45's air filter regularly, how often depends on the amount of dust in the ventilation air. Select what is most suitable for your installation.

Set the interval for the reminder in this menu.

The menu shows the time remaining until the next reminder, and you can also reset active reminders.

### MENU 1.2.2 - NIGHT COOLING

#### *Night cooling*

Setting range: on/off

#### *Start temp exhaust air*

Setting range: 20 – 30 °C

#### *Min. diff. ind. temp. - outd. temp.*

Setting range: 3 – 10 °C

#### *Night cooling during heating*

Setting range: on/off

Here, you can activate night cooling. When the temperature in the building is high, and the outdoor temperature is low, a cooling effect can be obtained by forcing the ventilation.

*Start temp exhaust air:* Here, you set the exhaust air temperature at which night cooling will start.

*Min. diff. ind. temp. - outd. temp.:* If the temperature difference is greater than the set value for "Min. diff. ind. temp. - outd. temp.", and the exhaust air temperature is higher than the set value for "Start temp exhaust air", the ventilation operates at speed 4 until one of these conditions is no longer valid.

*Night cooling during heating:* It is possible to have night cooling during the time heating is permitted.

### MENU 7.4 - SELECTABLE IN/OUTPUTS

Here you select the room sensor for FLM cooling (AZ10-BT50) on the relevant AUX input.

### MENU 1.2.3 - FLM COOLING

#### *Room set point value*

Setting range: 5 – 40 °C

#### *Cooling at room over temp*

Setting range: 1 – 10 °C

When you have activated FLM cooling in menu 7.2.2, set the desired room temperature in this menu. You also select the temperature at which cooling will start.

FLM cooling starts when the room temperature exceeds the set *Room set point value* + *Cooling at room over temp*.

FLM cooling stops when the room temperature falls below *Room set point value*.

In systems with several FLM, settings can be made for each FLM unit.


# 8 Service

## Service actions

### HELPING THE CIRCULATION PUMP TO START

1. Shut off FLM S45.
2. Remove the front cover
3. Remove the fan.
4. Loosen the venting screw (QM5) with a screwdriver. Hold a cloth around the screwdriver blade as a small amount of water may run out.
5. Insert a screwdriver and turn the pump motor around.
6. Screw in the venting screw (QM5).
7. Start FLM S45 and check that the circulation pump is working.

It is often easier to start the circulation pump with FLM S45 running. If the circulation pump is helped to start with FLM S45 running, be prepared for the screwdriver to jerk when the pump starts.



# 9 Disturbances in comfort

In most cases, the compatible heat pump notes a malfunction (a malfunction can lead to disturbance in comfort) and indicates this with alarms and action instructions in the display.

## Troubleshooting

If the malfunction does not appear in the display or FLM S45 is not connected to a compatible heat pump, the following tips can be used:

### BASIC ACTIONS

Start by checking the following items:

- That the heat pump is operating and the supply cable to FLM S45 is connected.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.

### LOW OR A LACK OF VENTILATION

- Filter (HQ10) blocked.
  - Clean or replace the filter.
- The ventilation is not adjusted.
  - Order/implement ventilation adjustment.
- Exhaust air device blocked or throttled down too much.
  - Check and clean the exhaust air devices.
- Fan speed in reduced mode.
  - If FLM S45 is connected to a compatible heat pump: Enter menu 1.2.1 and select "normal".
  - If FLM S45 is connected to another heat pump: Check the potentiometer (SF3).
- External switch for changing the fan speed activated.
  - Check any external switches.

### HIGH OR DISTRACTING VENTILATION

- Filter (HQ10) blocked.
  - Clean or replace the filter.
- The ventilation is not adjusted.
  - Order/implement ventilation adjustment.

- Fan speed in forced mode.
  - If FLM S45 is connected to a compatible heat pump: Enter menu 1.2.1 and select "normal".
  - If FLM S45 is connected to another heat pump: Check the potentiometer (SF3).
- External switch for changing the fan speed activated.
  - Check any external switches.

### GURGLING SOUND

- Not enough water in the water seal.
  - Refill the water seal with water.
- Choked water seal.
  - Check and adjust the condensation water hose.

# 10 Accessories

Detailed information about the accessories and complete accessories list available at [nibe.eu](http://nibe.eu).

Not all accessories are available on all markets.

Some accessories manufactured before 2019 may need to have their circuit board updated in order to be compatible with FLM S45. For more information, see the Installer Manual for the relevant accessory.

## BRACKET BAU 40

Wall mounting of FLM S45.

Part no. 067 666

## TOP CABINET TOC 30

Top cabinet, which conceals any pipes/ventilation ducts.

*Height 245 mm*

*Height 345 mm*

Part no. 067 517


Part no. 067 518

*Height 385-635 mm*

Part no. 067 519

# 11 Technical data

## Dimensions and setting-out coordinates



# Technical specifications

<i>FLM S45</i>		
<i>Electrical data</i>		
Supply voltage	V	230 V NAC 50 Hz
Max driving power circulation pump	W	70
Driving power fan	W	170
Enclosure class		IP21
<i>Ventilation</i>		
Max airflow	m <sup>3</sup> /h	350
<i>Brine circuit</i>		
Minimum incoming brine temperature	°C	-8
Maximum recommended incoming brine temperature	°C	15
Maximum outgoing brine temperature	°C	30
Min pressure brine	MPa/bar	0.02/0.2
Maximum pressure brine	MPa/bar	0.3/3
<i>Sound effect level according to EN 12 102</i>		
Sound power level (L <sub>W(A)</sub> ) <sup>1</sup>	dB(A)	35-48
<i>Miscellaneous</i>		
Width	mm	600
Depth	mm	556
Height	mm	396
Weight	kg	35
Part No.		067 627

<sup>1</sup> The value varies with the selected fan curve.






1 2 3 4 5 6 7 8

OPTIONAL CONNECTIONS:

DUCT FAN AND DAMPER



Dimension	Material Quality/Specification		Mass (kg)
Revision note	Rev. by	Rev. Checked by	Rev. table (YYYY-MM-DD)
	Status	Designer	Checked by
			Date (YYYY-MM-DD)
	Plant	Formal	Next sheet: Sheet: 2
	Location	Drawing no	Rev
		<b>051281</b>	<b>1</b>

WIR. DIAGRAM NIBE FLM/FLM S45  
ELSCHEMA, NIBE FLM/FLM S45

# Item register

## A

- Accessories, 29
- Another heat pump, 14
- Assembly, 7

## B

- Brine side, 13
  - Output transfer to brine, 13
  - Pressure expansion vessel, 13

## C

- Commissioning and adjusting, 21
  - Filling and venting, 21
  - Preparations, 21
  - Start-up and inspection, 22
- Compatible NIBE heat pumps, 8
- Condensation water hose, 14
- Connecting to another heat pump, 19
- Connecting to compatible heat pump, 17

## D

- Delivery and handling, 7
  - Installation area, 7
  - Removing the covers, 8
  - Supplied components, 8
- Dimensions and pipe connections, 13
- Dimensions and setting-out coordinates, 30
- Disturbances in comfort, 28
  - Troubleshooting, 28

## E

- Electrical connections, 17
  - Connecting to another heat pump, 19
  - Connecting to compatible heat pump, 17
  - Connections, 17
  - General, 17
- Exhaust air duct, 16

## F

- Filling and venting, 21
  - Filling and venting the brine system, 21
- Filling and venting the brine system, 21
- FLM cooling, 14

## G

- General pipe connections
  - Compatible NIBE heat pumps, 8
  - Installation alternative
  - FLM cooling, 14

## H

- Helping the circulation pump to start, 27

## I

- Important information, 4
  - Recovery, 4
  - Safety information, 4
- Installation alternative
  - Another heat pump, 14
- Installation area, 7

## M

- Marking, 4
- Mounting, 8–9
  - Connecting to another heat pump, 9
  - Connecting to F1145/F1155/F1245/F1255, 8

## O

- Outline diagram, 12
  - General pipe connections, 12
- Output transfer to brine, 13

## P

- Pipe and ventilation connections, 12
  - Brine side, 13
  - Condensation water hose, 14
  - Dimensions and pipe connections, 13
  - Exhaust air duct, 16
  - General pipe connections, 12
  - Mounting, 8
- Pipe connections
  - Symbol key, 12
- Preparations, 21
- Pressure expansion vessel, 13

## R

- Removing the covers, 8

## S

- Safety information, 4
  - Marking, 4
  - Serial number, 4
  - Symbols, 4
- Serial number, 4
- Service, 27
  - Service actions, 27
- Service actions, 27
  - Helping the circulation pump to start, 27
- Start guide, 25
- Start-up and inspection, 22
  - Setting the pump speed, 23

- Setting the ventilation, 23
- Starting-up with another heat pump, 22
- Start-up with compatible heat pump, 22
- Supplied components, 8
- Symbol key, 12
- Symbols, 4

## **T**

- Technical data, 30
  - Dimensions and setting-out coordinates, 30
  - Technical Data, 31
- Technical Data, 31
- The design of the exhaust air module, 10
  - List of components, 11
- Transport
  - Assembly, 7
- Troubleshooting, 28







## Contact information

### *AUSTRIA*

KNV Energietechnik GmbH  
Gahberggasse 11, 4861 Schörfling  
Tel: +43 (0)7662 8963-0  
mail@knv.at  
knv.at

### *CZECH REPUBLIC*

Družstevní závody Dražice - strojírna  
s.r.o.  
Dražice 69, 29471 Benátky n. Jiz.  
Tel: +420 326 373 801  
nibe@nibe.cz  
nibe.cz

### *DENMARK*

Vølund Varmeteknik A/S  
Industrivej Nord 7B, 7400 Herning  
Tel: +45 97 17 20 33  
info@volundvt.dk  
volundvt.dk

### *FINLAND*

NIBE Energy Systems Oy  
Juurakkotie 3, 01510 Vantaa  
Tel: +358 (0)9 274 6970  
info@nibe.fi  
nibe.fi

### *FRANCE*

NIBE Energy Systems France SAS  
Zone industrielle RD 28  
Rue du Pou du Ciel, 01600 Reyrieux  
Tél: 04 74 00 92 92  
info@nibe.fr  
nibe.fr

### *GERMANY*

NIBE Systemtechnik GmbH  
Am Reiherpfahl 3, 29223 Celle  
Tel: +49 (0)5141 75 46 -0  
info@nibe.de  
nibe.de

### *GREAT BRITAIN*

NIBE Energy Systems Ltd  
3C Broom Business Park,  
Bridge Way, S41 9QG Chesterfield  
Tel: +44 (0)845 095 1200  
info@nibe.co.uk  
nibe.co.uk

### *NETHERLANDS*

NIBE Energietechnik B.V.  
Energieweg 31, 4906 CG Oosterhout  
Tel: +31 (0)168 47 77 22  
info@nibenl.nl  
nibenl.nl

### *NORWAY*

ABK-Qviller AS  
Brobekkveien 80, 0582 Oslo  
Tel: (+47) 23 17 05 20  
post@abkqviller.no  
nibe.no

### *POLAND*

NIBE-BIAWAR Sp. z o.o.  
Al. Jana Pawla II 57, 15-703 Bialystok  
Tel: +48 (0)85 66 28 490  
biawar.com.pl

### *RUSSIA*

EVAN  
bld. 8, Yuliusa Fuchika str.  
603024 Nizhny Novgorod  
Tel: +7 831 288 85 55  
info@evan.ru  
nibe-evan.ru

### *SWEDEN*

NIBE Energy Systems  
Box 14  
Hannabadsvägen 5, 285 21 Markaryd  
Tel: +46 (0)433-27 3000  
info@nibe.se  
nibe.se

### *SWITZERLAND*

NIBE Wärmetechnik c/o ait Schweiz  
AG  
Industriepark, CH-6246 Altishofen  
Tel. +41 (0)58 252 21 00  
info@nibe.ch  
nibe.ch

For countries not mentioned in this list, contact NIBE Sweden or check [nibe.eu](http://nibe.eu) for more information.

NIBE Energy Systems  
Hannabadsvägen 5  
Box 14  
SE-285 21 Markaryd  
info@nibe.se  
nibe.eu

IHB EN 2115-1 631218

This manual is a publication from NIBE Energy Systems. All product illustrations, facts and data are based on the available information at the time of the publication's approval. NIBE Energy Systems makes reservations for any factual or printing errors in this manual.

©2021 NIBE ENERGY SYSTEMS

